



**Typical wiring for use with a Gecko servo-drive,** To use with other types of drives such as stepper-type that require no feedback, connection to the encoder is all that is required. And is the same basic configuration for any type of 5VDC input device i.e. MPG's, OEM triggers, Probes etc.